

To CHANGE SYSTEM TIME ON PANASONIC DBS 576

Enter User Maintenance Mode:

Press **ON/OFF** key
Press **PROG** key
Press the * key twice (**)
Press **CONF** key
Display will read:

81- User MAINT

Enter 000

Press the **HOLD** key
Display will read:

0 :YMMDD Date

Enter the year, month, and day (two characters)

Press the **HOLD** key
Display will read:

1 :HHMM Time

Enter the hour and minute (two characters)

Press the **HOLD** key
Display will read:

2 : Day of the Week

Enter the day of the week (Sun = 0, Mon = 1, etc.)

Press **HOLD**

To return to the top menu level press the **PROG** key or Press **ON/OFF** to end.

 **NOTE: To clear an entry or existing data, press the FLASH key**